


## Plywood Foundation Installation Instructions




The plywood foundation consists of 4 sheets of plywood and 5 - 2x4 slats.


Place the slats between the front and back rails evenly spacing them based on the width of the plywood.

Attach the slat to the front and back rails using one 2-1/2" screw at each end.

Attach the plywood to the slat using five 1-5/8" screws for each slat as shown using the above arrows.

Note, when screwing into plywood, you must be at least 3/4" away from the edge of the plywood.

 Plywood - Qty 4, labeled above as P1 - P4

 2x4 Slat - Qty 5, labeled above as S1 - S5